



Einstellen der Endschalter für DSZY2, DSZY3, DSZY5 und DSZY6



Note 1 : To avoid damaging the plastic gears under the Limit Cam, please hold Upper & Lower Limit Cam when you tighten or loosen the cam's screw .